



**1** Position END/REAR or MID bracket onto existing desk surface and secure with two grub screws

**2** Place brackets around 100 to 200mm from edge of desk or to suit desk frame



**3** Adhere rubber pad to glass panel the same distance inset as the bracket



**4** Carefully place glass panel into bracket with black rubber pad towards grub screws



**5** Carefully evenly tighten grub screws to secure glass panel, not over tightening